

DIGITAL REVERB DR600

Digital Stereo Reverb Effects Pedal

Thank you for showing your confidence in us by purchasing the BEHRINGER DIGITAL REVERB DR600. This ultimate effects pedal is specifically designed to deliver 24-bit high-resolution stereo reverbs comparable to state-of-the-art studio processors. Thanks to six renowned modes and extensive parameter control for maximum creativity you'll have plenty of cool sounds at your disposal for every situation.

1. Controls



- 1 The **LEVEL** control adjusts the output level.
- 2 The **TONE** control allows you to shape your overall sound.
- 3 The **TIME** control determines the reverb time.
- 4 The **MODE** control lets you choose between six different reverb sounds:
 - SPRING:** Simulates classic spring reverberation.
 - PLATE:** Simulates the sound of plate reverberation.
 - HALL:** Very bright reverb that simulates the reflections of a concert hall.
 - GATE:** This effect synthetically cuts off reverberation after a period of time.
 - ROOM:** Clearly hear natural room acoustics.
 - MODULATE:** By detuning the reverb tail it creates spacious, almost choir-like reverb that reminds a little bit of a chorus effect.
- 5 The **ON/BATT** LED illuminates when the effect is activated. It also serves as a battery level indicator.
- 6 Use the footswitch to activate/deactivate the effect.
- 7 Use the two 1/4" TS connectors **IN A** and **IN B** to plug in a stereo input signal. For mono use just plug in IN A.
- 8 The two 1/4" TS connectors **OUT A** and **OUT B** send the signal to your amp. Use both connectors if you want to achieve full stereo effect. For mono use just plug in OUT A.

Use the **DC IN** connection to plug in a 9 V power supply (not included).

The **BATTERY COMPARTMENT** is located underneath the pedal cover. To install or replace the 9 V battery (not included), press the hinges with a ballpoint pen and remove the pedal cover. Be careful not to scratch the unit.

♦ **The DR600 has no on/off switch. As soon as you insert the jack into the IN connector, the DR600 begins running. When not using the DR600, remove the jack from the IN connector. This extends the life of the battery.**

The **SERIAL NUMBER** is located at the bottom.

2. Safety Instructions

Do not use near water, or install near heat sources. Use only authorized attachments/accessories. Do not service product yourself. Contact our qualified servicing personnel for servicing or repairs, especially when power supply cord or plug is damaged.

3. Warranty

Please register your new BEHRINGER equipment right after your purchase by visiting <http://behringer.com> and read the terms and conditions of our warranty carefully.

4. Specifications

In A

Connector	¼" TS
Impedance	500 kΩ
Impedance mono	250 kΩ

In B

Connector	¼" TS
Impedance	500 kΩ

Out A

Connector	¼" TS
Impedance	1 kΩ

Out B

Connector	¼" TS
Impedance	1 kΩ

Power Supply

9 V --- , 100 mA regulated

BEHRINGER PSU-SB

U.S./Canada	120 V~, 60 Hz
China/Korea	220 V~, 50 Hz
U.K./Australia	240 V~, 50 Hz
Europe	230 V~, 50 Hz
Japan	100 V~, 50 - 60 Hz
Power connector	2 mm DC jack, negative center
Battery	9 V type 6LR61
Power consumption	30 mA

Physical/Weight

Dimensions (H x W x D)	approx. 2 ½ x 2 ¾ x 4 ½" approx. 54 x 70 x 123 mm
Weight	approx. 0.73 lbs / 0.33 kg

BEHRINGER is constantly striving to maintain the highest professional standards. As a result of these efforts, modifications may be made from time to time to existing products without prior notice. Specifications and appearance may therefore differ from those listed or shown.

TECHNICAL SPECIFICATIONS AND APPEARANCES ARE SUBJECT TO CHANGE WITHOUT NOTICE AND ACCURACY IS NOT GUARANTEED. BEHRINGER IS PART OF THE MUSIC GROUP (MUSIC-GROUP.COM). ALL TRADEMARKS ARE THE PROPERTY OF THEIR RESPECTIVE OWNERS. MUSIC GROUP ACCEPTS NO LIABILITY FOR ANY LOSS WHICH MAY BE SUFFERED BY ANY PERSON WHO RELIES EITHER WHOLLY OR IN PART UPON ANY DESCRIPTION, PHOTOGRAPH OR STATEMENT CONTAINED HEREIN. COLORS AND SPECIFICATIONS MAY VARY FROM ACTUAL PRODUCT. MUSIC GROUP PRODUCTS ARE SOLD THROUGH AUTHORIZED FULLFILLERS AND RESELLERS ONLY. FULLFILLERS AND RESELLERS ARE NOT AGENTS OF MUSIC GROUP AND HAVE ABSOLUTELY NO AUTHORITY TO BIND MUSIC GROUP BY ANY EXPRESS OR IMPLIED UNDERTAKING OR REPRESENTATION. THIS MANUAL IS COPYRIGHTED. NO PART OF THIS MANUAL MAY BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING AND RECORDING OF ANY KIND, FOR ANY PURPOSE, WITHOUT THE EXPRESS WRITTEN PERMISSION OF MUSIC GROUP IP LTD. ALL RIGHTS RESERVED. © 2012 MUSIC Group IP Ltd. Trident Chambers, Wickhams Cay, P.O. Box 146, Road Town, Tortola, British Virgin Islands